BROOKHAVEN NATIONAL LABORATORY PHYSICS DEPARTMENT		Number: PO-P-ATF-0027  Effective: 08/17/2011		Revision: 0
				Page: 1 of 1
Subject: RF Gun cathode replacement procedure			Prepared by: Mark Montemagno	
Reviewed by ESH Coordinator: Approved by ATF Head:		Approved by Department Chair:  Luellam		

## RF Gun cathode replacement procedure

- 1. With Gun water flowing and Gun temperature stabilized, physically measure the gap between the cathode and Gun in 4 places with feeler gauges.
- 2. Remove RF load
- 3. Install RF launcher
- 4. Network Analyzer Forward to launcher
- 5. Network Analyzer Reverse to Gun Reverse
- 6. (With Gun chiller on and Gun temperature stabilized) Measure 2 peaks under vacuum (should be about 3MHz apart)
- 7. Record frequencies of 2 peaks; Measurement #1; one peak should be 2856 precisely
- 8. Fill Gun with N2.
- 9. Measure the 2 peaks again; Measurement #2. (peaks should shift by about 1MHz)
- 10. Turn off water. If: gun is cooler that ambient Then: allow it to warm up.
- 11. Bleed up gun with N2.
- 12. Remove old cathode with N2 flowing.
- 13. Hand tighten the new cathode in place
- 14. Observe the network analyzer; continue to uniformly torque the cathode bolts until the network analyzer shows 2 peaks
- 15. At about 0.005" before physical measurement in step 1, pump out and leak check
- 16. Continue to torque bolts (Torque the bolts closest to detected leak first)
- 17. End Result:
  - 1. Cathode needs to be parallel to Gun, worst case 0.001" off.
  - 2. No Leaks
  - 3. Frequency peaks match Measurement #1, (amplitude not critical)
- 18. All Ion pumps should be on; pump-out port should be closed and sealed
- 19. Turn on Gun water. Allow Gun temperature to stabilize.
- 20. Once Gun temperature is stabilized and RF peaks look good, do a final check for water leaks and be sure all tools have been removed from the area.
- 21. Call Marcus, ask to install Gun Cathode camera and check optical alignments
- 22. Close Clam shell and prepare for Gun/cathode conditioning
- 23. Remove launcher and replace RF load